


## CR SERIES: Changing the face panel


Unlike most front-loading refrigerators, the CR Series face panel is interchangeable—while installed in your boat or RV.



1. Remove rubber gasket from the interior door.



2. Unfasten the 4 screws with a Phillips screwdriver.



3. Remove the door handle by pulling up until the entire piece is removed.



4. Remove the existing face panel, by sliding it up and out of the door surround.

{Photo right shows unit with the face panel completely removed.}



5. Slide in preferred face panel.

Re-insert door handle, re-fasten 4 screws, re-apply rubber gasket.